# FAVORIT 86050

## Fully Integrated Dishwasher

## User Instructions



## Dear customer,

Please read these user instructions carefully.

Please observe the safety instructions on the first few pages of these user instructions! Please keep these user instructions for later reference. Pass them on to any subsequent owner of the appliance.

The warning triangle and/or specific words (**Warning!**, **Caution!**, **Important!**) are used to highlight instructions that are important for your safety or for the function of the appliance. It is imperative that these instructions are observed.

This symbol or numbered instruction steps lead you step by step through the operation of the appliance.

Next to this symbol you receive additional information and practical tips on using the appliance.

Tips and instructions for the economical and environmentally conscious use of the appliance are marked with a clover leaf.

In the event of a malfunction, these operating instructions contain information on how to rectify faults yourself, see the "What to do, if..." section.

If these instructions are insufficient, please contact your AEG Service Force Centre.

In this respect please read the chapter "Service & Spare Parts".

Printed on paper manufactured with environmentally sound processes. He who thinks ecologically acts accordingly ...

# CONTENTS


## Operating Instructions ..... 5

**Safety Instructions** ..... 5

**Disposal** ..... 7

**Economical and Ecological Dishwashing** ..... 7

**Appliance Features, Display and Control Fields** ..... 8
- Display and Control Panels ..... 9

**Prior to using for the first time** ..... 10
Adjusting the Water Softener ..... 10
Filling with Salt for the Water Softener ..... 12
Rinse Aid ..... 13
- Switching Rinse Aid Supply On and Off ..... 13
- Filling with Rinse Aid ..... 14
- Adjusting Rinse Aid Dosing ..... 15

Switching the Acoustic Signal for the End of the Wash Programme On and Off ..... 15

**In Daily Use** ..... 16
Loading Cutlery and Dishes ..... 16
- Loading Cutlery ..... 17
- Loading Pans, Frying Pans and Large Plates ..... 19
- Loading Cups, Glasses and Coffee Services ..... 20
- Adjusting the Height of the Upper Basket ..... 21

Filling with Detergent ..... 22
- Concentrated Detergent ..... 23
- Detergent tablets ..... 23
- Automatic Wash Programmes ..... 23

Selecting the Wash Programme (Programme Table) ..... 24
Start the Wash Programme ..... 25
- Deleting a Wash Programme ..... 25
- Interrupting the Wash Programme (only in emergencies) ..... 26
- Setting or Changing the Delay Start Timer ..... 26
- Load Sensing – Sensor Logic ..... 27

Switching Off the Dishwasher ..... 27
- Emptying the Dishwasher ..... 27

**Care and Cleaning** ..... 28
- Cleaning the Filter ..... 28

**What to do, if ...** ..... 29
... Warning tones indicating a fault in the dishwasher. ..... 30
...there are problems with the operation of the dishwasher. ..... 31
...the wash result is not satisfactory. ..... 31

**Technical Data** ..... 32

**Notes for Test Institutes** ..... 33

## Installation and Connection Instructions ..... 34

**Installing the Dishwasher** ..... 34

**Fitting the Furniture Door Panel** ..... 35

**Connecting the Dishwasher** ..... 36
Water Connection ..... 36
- Permitted water pressure ..... 36
- Connect the inlet hose ..... 36
- Water drain ..... 38
- Leak Prevention System ..... 39

Electrical Connection ..... 40
Connections ..... 41

## Guarantee Conditions ..... 42

## Service and Spare parts ..... 43

# OPERATING INSTRUCTIONS

## ⚠ Safety Instructions

The safety aspects of AEG electrical appliances comply with accepted technical standards and the German Appliance Safety Law. Nevertheless, as a manufacturer we consider it our obligation to make you aware of the following safety information:

### Installation, Connection and Placing into Operation

- The dishwasher may only be transported upright.
- Check the dishwasher for transport damage. Do not in any circumstances connect an appliance that is damaged. In the case of damage, please contact your retailer.
- Before installing the appliance, ensure that the nominal voltage and type of supply on the rating plate match that of the supply where the appliance is to be installed. The fuse rating is also to be found on the rating plate.
- For information on how to correctly install and connect up your dishwasher, please read the “Installation“ section. Adaptors / connectors and extension cables must not be used.

### Child Safety

- This appliance is designed to be operated by adults. Children should not be allowed to tamper with the controls or play with the product.
- Keep all packaging away from children.
- Keep all detergents in a safe place out of children’s reach.
- The water in your dishwasher is not suitable for drinking. If there are still remnants of detergent in the appliance, there is a risk of burns!
- When disposing of an old appliance, cut off the power supply cable and remove any door catches, to prevent young children being trapped inside.

### General Safety

- Repairs to the dishwasher are only to be carried out by qualified service engineers. Improper repairs can give rise to significant hazards for the user. If your appliance needs repairing, please contact your local AEG Service Force Centre.

- Never place the dishwasher in operation if the mains cable, water inlet or drain hose is damaged; or the control panel, work top or plinth area is damaged such that the inside of the appliance is freely accessible.
- If the mains lead is damaged, or is to be replaced for a longer lead, the cable (obtainable from AEG Service Force) must be changed by a service engineer authorised by AEG.
- Never unplug the appliance by pulling on the cable, always pull the plug.
- Additions or modifications to the dishwasher are not permitted for safety reasons.
- Ensure that the door of the dishwasher is always closed when it is not being loaded or unloaded. In this way you will avoid anybody tripping over the open door and hurting themselves.
- Long bladed knives stored in an upright position are a potential hazard.
- Sharp knives and items of cutlery with sharp edges must be placed in the cutlery tray or in the upper rack.
- When finished loading or unloading, close the door as an open door can be a hazard.

## Correct Use

- Only wash household dishes using the dishwasher. If the appliance is used for other purposes, or is used incorrectly, the manufacturer cannot accept any liability for any damage caused.
- Only use detergents specifically designed for use in domestic dishwashers.
- Do not put any solvents in the dishwasher. There is a risk of an explosion!
- The anti-flood system provides dependable protection against damage due to leaks. For this system to function correctly, the following preconditions must be met:
  – The appliance must remain connected to the mains even when it is switched off.
  – The dishwasher must be correctly installed.
  – Always shut off the water supply at the tap when the dishwasher is not to be used for longer periods, e.g. when you are away on holiday.
- Do not sit or stand on the open door, the appliance may tip over.

- In the event of a fault, first close the tap, then switch off the appliance and unplug it from the mains. If the appliance is permanently wired to the mains: remove the fuse.

# Disposal

## Disposing of the Packaging Material

Dispose of the dishwasher packaging material correctly. All the packaging materials used are harmless to the environment and can be recycled.

- Plastic parts are marked with standard international abbreviations:
  – >PE< for polyethylene, e.g. sheet wrapping material
  – >PS< for polystyrene, e.g. padding material (always CFC-free)
  – >POM< for polyoxymethylene, e.g. plastic clips
- Cardboard packaging is manufactured from recycled paper and should be deposited in the waste paper collection for recycling.

## Disposal of Old Appliances

When disposing of old appliances, remove the plug and ensure that any locks or catches are removed to prevent young children becoming trapped inside.

Use an authorised disposal site.

# Economical and Ecological Dishwashing

- Ensure that the water softener is correctly adjusted.
- Do not pre-rinse dishes under running water.
- If you wash a small load, the load sensor calculates the amount of water necessary and shortens the programme. It is more economical to always wash with a full load.
- Select the wash programme to suit the nature and degree of the soiling on the dishes.
- Do not use more detergent, special salt or rinse aid than is recommended in these operating instructions and by the detergent manufacturer.
- The dishwasher's interior light is always switched on as long as the door of the appliance is open. To save energy you should therefore always close the door of the dishwasher after loading or removing dishes.

# Appliance Features, Display and Control Fields



# Display and Control Panels




The **control panel** consists of the ON/OFF button and the programme buttons with LED displays.

**Function buttons:** In addition to the stated wash programme the following functions can also be set using these buttons:

| | |
|---|---|
| **Function button 1** | Switch acoustic signal on and off |
| **Function button 2** | Adjust the water softener |
| **Function button 3** | Switch rinse aid supply on and off |
| **Function button 4** | - is not occupied - |

**Indicators** have the following significance:

| | |
|---|---|
| | Refill with special salt |
| | Refill with rinse aid |
| | Open the tap |

# Prior to using for the first time

Prior to using for the first time, remove all the clips with which the dish racks are secured for transport.
Then perform the following steps:

☞ **1.** Adjust the water softener
**2.** Fill with Salt for the Water Softener
**3.** Fill with Rinse Aid

## Adjusting the Water Softener

To prevent the build up of scale on dishes and in the dishwasher, the dishes must be washed with soft, i.e. low lime content water. For this reason the dishwasher is fitted with a water softener in which tap water from a hardness of 4 °d (German degree) is softened with the aid of special salt.

ⓘ Your local water authority can advise you on the hardness of the water in your area.

☞ Adjust the water softener as stated in the table to the setting that corresponds to the hardness of the water in your area. The water softener can be set manually using the water hardness switch and also electronically using the buttons on the control panel.

<table>
<tr><th colspan="3">Water Hardness</th><th colspan="2">Hardness Setting</th><th rowspan="2">Number of Flashes</th></tr>
<tr><th>in °d[1])</th><th>in ppm[2])</th><th>Range</th><th>Manual</th><th>Electronic</th></tr>
<tr><td>51 - 70<br>43 - 50<br>37 - 42<br>29 - 36<br>23 - 28</td><td>9,0 - 12,5<br>7,6 - 8,9<br>6,5 - 7,5<br>5,1 - 6,4<br>4,0 - 5,0</td><td>IV</td><td>1</td><td>9<br>8<br>7<br>6<br>5</td><td>9<br>8<br>7<br>6<br>5</td></tr>
<tr><td>19 - 22<br>15 - 18</td><td>3,3 - 3,9<br>2,6 - 3,2</td><td>III</td><td rowspan="4">0*</td><td>4<br>3*</td><td>4<br>3</td></tr>
<tr><td>11 - 14</td><td>1,9 - 2,5</td><td>II</td><td>2</td><td>2</td></tr>
<tr><td>4 - 10</td><td>0,7 - 1,8</td><td>I/II</td><td>1</td><td>1</td></tr>
<tr><td>under 4</td><td>under 0.7</td><td>I</td><td>0<br>no salt necessary</td><td>10</td></tr>
</table>

1)(°d) German degrees, a measure of water hardness
2)(ppm), Parts Per Million
*factory setting

Adjust the water softener to the hardness of the water in your area as stated in the table:




☞ **1.** The dishwasher must be switched off.

**2. Manual adjustment:**
Open the dishwasher door.

**3.** Remove the lower rack from the dishwasher.

**4.** Turn the water hardness switch to 0 or 1.

**5.** Re-position the lower rack.

**6. Electronic adjustment:**
Simultaneously press and hold down function buttons **1** and **2**.

**7.** Press the ON/OFF button.
The LED displays for the engaged function buttons will flash.

**8.** Press function button **2** again.
– The LED display for function button **2** will flash.
– The number of flashes corresponds to the hardness setting. (Exception: hardness setting 0 is indicated by 10 flashes).
– The sequence of flashes is repeated several times after a 5 second pause.

**9.** Pressing function button **2** increases the hardness setting by 1. (Exception: hardness setting 0 follows hardness setting 9).

**10.** Once the hardness setting is set correctly, press the ON/OFF switch. The hardness setting is then saved.

## Filling with Salt for the Water Softener

⚠ Use only salt designed for dishwashers. Never fill the salt container with any another type of salt (e.g. culinary salt) or dishwasher detergent as this would irreparably damage the water softener.
Prior to filling with salt, please check each time that you really do have a packet of dishwasher salt in your hand.

**Fill with dishwasher salt:**
– Prior to using the dishwasher for the first time
– When the SALT indicator ⇄ on the control panel is illuminated.

ⓘ If the water hardness in your area is less than 4 °d, you do not need to use dishwasher salt. The SALT indicator ⇄ on the control panel will remain illuminated.

☞ **1.** Open the door, remove the lower rack.

**2.** Undo the lid on the salt container by turning it anticlockwise.

**3. When using for the first time:** fill the salt container with water.

**4.** Place the funnel supplied on the container opening.
Fill the container with salt through the funnel; the capacity of the container is approx. 1.0-1.5 kg depending on the grain size. Do not overfill the salt container with salt.




ⓘ The water expelled by filling the salt container with salt runs out of the salt container onto the base of the washing compartment. This is not a cause for concern, the water will be pumped out at the start of the next wash programme.

**5.** Clean any salt remnants on the container opening.

**6.** Turn the lid clockwise to the stop, otherwise dishwasher salt will leak into the wash water, this could lead to poor wash results. To avoid this run a rinse programme after filling the salt container with special salt. This will wash away salt water and any salt crystals that have been spilt.

ⓘ Depending on the size of the salt grains, it can take several hours for the salt to dissolve in the water and the special salt indicator ⇄ to extinguish. The setting of the water softener and the consumption of salt are dependent on the hardness of the local water.

## Rinse Aid

Rinse aid ensures that dishes emerge thoroughly rinsed and spot free while glasses are clear and shining.

**There are two ways to add rinse aid:**

- If you use detergent that already contains rinse aid, the detergent and rinse aid are placed in the detergent container.
  – In this case the rinse aid supply from the rinse aid container must be **switched off** to avoid double dosing.
- If you use separate detergent and rinse aid, the rinse aid is placed in the rinse aid container.
  – In this case the rinse aid supply from the rinse aid container must be **switched on**.
  – Rinse aid dosing levels need to be set.

⚠ Only use rinse aid specifically designed for domestic dishwashers. Never fill the rinse aid container with any other substance (e.g., vinegar concentrate or dishwasher cleaning agent) as this would damage the appliance.

### Switching Rinse Aid Supply On and Off

☞ **1.** The appliance must be switched off.

**2.** Simultaneously press and hold down function buttons **1** and **2**.

**3.** Press the ON/OFF switch.
The LED displays for the engaged function buttons will flash.

**4.** Press function button **3**.
The LED display for function button **3** will flash.

**5.** The display →| shows the current setting:

| | |
|---|---|
| Display →| flashes: | Rinse aid supply switched on (factory setting) |
| Display →| does not flash: | Rinse aid supply switched off |

**6.** Pressing function button **3** switches the rinse aid supply on and off.

**7.** Once the rinse aid supply is set correctly, press the ON/OFF switch.
The setting for the rinse aid supply is then saved.

## Filling with Rinse Aid

If you use separate detergent and rinse aid, fill up with rinse aid:

– prior to using the dishwasher for the first time
– when the indicator ✳ is illuminated on the control panel.

The rinse aid compartment is on the inside of the dishwasher door.

☞ **1.** Open the door.

**2.** Press the rinse aid compartment release button with your finger.

**3.** Fully open the rinse aid compartment lid.



**4.** Fill with rinse aid exactly up to the level marked “max”; this corresponds to a quantity of approx. 140 ml.

**5.** Close the lid and press until it locks into place.

**6.** Wipe up any spilt rinse aid with a cloth. Otherwise too much foam will be formed during the wash.



## Adjusting Rinse Aid Dosing

As the dishes are washed rinse aid is released from the dispenser into the wash water. The dose is factory set at 4, and can be adjusted from 1 to 6. Only change the setting if streaks, milky spots or dried on water marks are visible on glasses or crockery.

☞ **1.** Open the door of the dishwasher.
**2.** Press the rinse aid compartment release button with your finger.
**3.** Fully open the rinse aid compartment lid.
**4.** Set the dose level.
**5.** Close the lid and press until it locks into place.
**6.** If rinse aid has run out, wipe up with a cloth.



## Switching the Acoustic Signal for the End of the Wash Programme On and Off

In addition to the visual indication the dishwasher can be set to emit an audible signal at the end of a wash cycle.

☞ **1.** The dishwasher must be switched off.
**2.** Simultaneously press and hold down function buttons **1** and **2**.
**3.** Press the ON/OFF button. The LED displays for the engaged function buttons will flash.
**4.** Press function button **1**.
The display →| shows the current setting:

| | |
|---|---|
| Display →| flashes: | Acoustic signal switched on (factory setting) |
| Display →| does not flash: | Acoustic signal switched off |

**5.** Pressing function button **1** changes the setting.
**6.** Once the display →| shows the required setting, press the ON/OFF button. The setting is then saved.

# In Daily Use

- Check the salt and rinse aid levels.
- Load cutlery and dishes into the dishwasher
- Fill with dishwasher detergent
- Select a wash programme suitable for the cutlery and dishes
- Start the wash programme

## Loading Cutlery and Dishes

Sponges, household cloths and any object that can absorb water should not be washed in the dishwasher.

| For washing in the dishwasher the following cutlery/dishes | |
|---|---|
| **are not suitable:** | **are of limited suitability:** |
| • Cutlery with wooden, horn, china or mother of pearl handles<br>• Plastic items that are not heat resistant<br>• Older cutlery with glued parts that is not temperature resistant<br>• Bonded cutlery items or dishes<br>• Pewter or copper items<br>• Lead crystal glass<br>• Steel items subject to rusting<br>• Wooden platters<br>• Items made from synthetic fibres | • Only wash stoneware in the dishwasher if it is specifically marked as being dishwasher-safe by the manufacturer.<br>• Glazed patterns may fade if machine washed frequently.<br>• Silver and aluminium parts have a tendency to discolour during washing. Left-overs, e.g. egg white, egg yolk and mustard often cause discolouring and staining on silver. Therefore always clean left-overs from silver immediately, if it is not to be washed straight after use.<br>• Some types of glass can become dull after a large number of washes. |

- Before loading the dishes, you should:
  – Remove all scraps of food.
  – Soften remnants of burnt food in pans.
- When loading the dishes and cutlery, please note:
  – Dishes and cutlery must not impede the rotation of the spray arms.
  – Load hollow items such as cups, glasses, pans, etc. with the opening downwards so that water cannot collect in the container or a deep base.
  – Dishes and items of cutlery must not lie inside one another, or cover each other

– To avoid damage to glasses, they must not touch
– Do not lay small objects (e.g. lids) in the cutlery rack

## Loading Cutlery

⚠ Long bladed knives stored in an upright position are a potential hazard.

⚠ Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket.

⚠ Take care when loading or unloading sharp items such as knives.

☞ Place knives, small spoons and small forks in the cutlery tray.



Place forks and spoons that do not fit in the cutlery tray in the cutlery basket.
To ensure that all items of cutlery in the cutlery basket are properly washed, you should




☞ **1.** Place the grid insert on the cutlery rack

**2.** Place forks and spoons in the grid insert on the cutlery basket with the handle downwards.

**3.** For larger items of cutlery, e.g. a whisk, half of the top for the cutlery basket can be left off.




**On some models of dishwasher** it is possible to open the cutlery basket.



⚠ To ensure that the cutlery basket cannot open on removal from the appliance, you should always hold both parts of the two part handle.

☞ **1.** Place the cutlery basket on a table or work surface

**2.** Open the two part handle

**3.** Remove cutlery

**4.** Close the two part handle.

## Loading Pans, Frying Pans and Large Plates

Load large and heavily soiled dishes in the lower rack.



To ease the loading of large items **at some dishwasher-models** the two rows of prongs for the right-hand plate insert can be folded down:

☞ **1.** Slightly lift the right plate insert.



**2.** Fold the plate insert to the left.



## Loading Cups, Glasses and Coffee Services

Load small, delicate items and long pointed cutlery in the upper rack.



- Arrange items of crockery on the folding cups racks so that they are offset from each other and water can reach all items.
- The cup racks can be folded up out of the way for tall items.
- Lay or hang wine, champagne, and brandy glasses in the cut outs on the cup racks.
- Glasses, beakers, etc. can also be placed on the two rows of prongs on the left of the upper rack.



## Adjusting the Height of the Upper Basket

| | Maximum Height of the Dishes in the Upper Basket | Lower Basket |
|---|---|---|
| With upper basket raised | 22 cm | 31 cm |
| With upper basket lowered | 24 cm | 29 cm |

The height of the basket can also be adjusted when it is loaded.

**Lowering the Upper Basket:**

☞ **1.** Pull the upper basket out completely.

**2.** Holding the upper basket at the rear right, lift it as far as it will go and then lower it vertically. The upper basket will engage in the lower position.



**Raising the Upper Basket:**

☞ **1.** Pull the upper basket out completely.

**2.** Holding the upper basket at the rear right, lift it as far as it will go and then lower it vertically. The upper basket will engage in the higher position.

## Filling with Detergent

Only use dishwasher detergent.

**Fill with detergent:**

– Prior to the start of a wash programme (not for the pre wash programme). The detergent is released into the wash water during the programme.

Please observe the manufacturer's dosing and storage recommendations as stated on the detergent packaging.

The detergent compartment is on the inside of the dishwasher door.




☞ **1.** If the lid is closed:
press release button (1).
The lid springs open.

**2.** Fill the detergent dispenser with detergent. The markings indicate the dosing levels:
"20" corresponds to approx. 20 ml of detergent,
"30" corresponds to approx. 30 ml of detergent.




**3.** Close the lid and press until it locks into place.

If the dishes are very heavily soiled put additional detergent into the adjacent chamber (2). This detergent will take effect during the pre wash.

## Concentrated Detergent

Based on their chemical composition, dishwasher detergents can be split into two basic types:
– **conventional**, alkaline **detergents** with caustic components
– low alkaline **concentrated detergents** with natural enzymes.

The use of 50 °C wash programmes in conjunction with concentrated detergents reduces pollution and is good for your dishes; these wash programmes are specially matched to the dirt-dissolving properties of the enzymes in the concentrated detergent. For this reason 50 °C wash programmes in which concentrated detergents are used can achieve the same results that can otherwise only be achieved using 65 °C programmes.

## Detergent tablets

**Detergent tablets** of different makes dissolve at different speeds. For this reason some detergent tablets cannot develop their full cleaning power during short programmes. Therefore please use normal programmes with pre wash when using detergent tablets.

## Automatic Wash Programmes

During the AUTOMATIC programmes the amount of soiling on the dishes is determined by how cloudy the water is.
If the appliance is partially loaded and the dishes lightly soiled, the “pre wash”, “main wash” and “rinsing” elements of the programme are shorter and the water consumption level is lower.
If the appliance is fully loaded and the dishes heavily soiled, the “pre wash”, “main wash” and “rinsing” elements of the programme are longer and the water consumption level is higher.
For this reason the programme duration, water and energy consumption levels can vary within the stated range for AUTOMATIC programmes (see Programme Table).
In this way, the dishes are always optimally washed while water and electricity consumption are kept low.

During AUTOMATIC programmes the temperature of the wash water is also automatically adjusted to between 50 °C and 65 °C depending on the amount of soiling on the dishes.

# Selecting the Wash Programme (Programme Table)

Choose the most suitable wash programme with the aid of this table: [1]

| Type of Dishes | Dinner Service and Cooking Utensils | | Dishes without Pans | Coffee Service and Dessert Dishes | |
|---|---|---|---|---|---|
| **In Addition** | - | - | - | with delicate glasses | |
| **Type of Soiling** | • heavily soiled<br>• dried on left-overs, particularly egg white and thickeners | • average soiling<br>• dried-on left-overs | • just used, average to slightly soiled | • average to slightly soiled | • slightly soiled |
| | | | particularly suitable when concentrated detergents are used. | | |
| **Suitable Programme:** | ⇩ | ⇩ | ⇩ | ⇩ | ⇩ |
| | INTENSIV 70° | AUTO | 30 MIN [4] | ECO 50° [5] | 40° |
| **Programme Sequence** [2] | Pre wash<br>Main wash<br>2x Rinsing<br>Final rinse<br>Drying | Pre wash<br>Main wash<br>Rinsing<br>Final rinse<br>Drying | -<br>Main wash<br>-<br>Final rinse<br>- | Pre wash<br>Main wash<br>Rinsing<br>Final rinse<br>Drying | -<br>Main wash<br>Rinsing<br>Final rinse<br>- |
| **Consumption Figures:** [3] | ⇩ | ⇩ | ⇩ | ⇩ | ⇩ |
| **Duration** | 110 - 120 min. | 95 - 115 min. | 30 min. | 130 - 150 min. | 35 min. |
| **Energy** | 1.75 - 1.95 kWh | 1.10 - 1.35 kWh | 0.8 kWh | 0.95 -1.05 kWh | 0.7 kWh |
| **Water** | 19 - 21 litres | 11.5 - 19 litres | 8 litres | 12 -14 litres | 11 litres |

[1] In addition to the wash programmes given in the table there is the special programme Pre wash. Using this programme you can give an initial wash to dishes that are to be stored in the dishwasher ready to be washed later. The special programme Pre wash lasts 12 minutes and uses 4 litres of water and less than 0.1 kWh of energy.

[2] Noise levels vary at different stages of the wash programme as at some programme stages the dishes are washed more energetically so that they will be cleaned more thoroughly.

[3] The consumption figures were determined under standard conditions. They are intended as a guide only and depend on the loading. For this reason figures may vary in practice.

[4] This programme is not suitable when left-overs have dried on.

[5] Test programme for test institutes

## Start the Wash Programme

☞ **1.** Open the door of the dishwasher.

**2.** Check that when the dishes and cutlery are loaded into the dishwasher the spray arms are free to rotate.

**3.** Open the tap fully.

**4.** Press the ON/OFF button. The indicator in the ON/OFF button illuminates.

**5.** Press the programme button for the desired programme (see "Programme Table"). The programme indicator illuminates.

**Have you accidentally selected the wrong wash programme?**

- If you want to change the wash programme within 6 seconds of making a programme selection, briefly press the button for the new wash programme.
- If you want to change the wash programme at a later point in time, use the following procedure:
  – Press the button for the new wash programme and hold it pressed. The indicators for both programmes now flash.
  – After a few seconds only the indicator for the new programme flashes. Release the programme button, the new wash programme has been saved.

**6.** Close the door. After around 6 seconds the selected wash programme begins.

ⓘ If acoustic warning tones can be heard after the start of the programme, please read the "What to do, if..." section.

## Deleting a Wash Programme

A selected wash programme can only be deleted when the door of the dishwasher is still open, however a programme cannot be deleted in the first 6 seconds after making a programme selection.
After 6 seconds the wash programme can be deleted as follows:

☞ **1.** Press the button for the current wash programme and hold it pressed. The programme indicator for the current wash programme flashes for a few seconds and then extinguishes.

**2.** Release the programme button, the wash programme is deleted.

ⓘ A selected programme is not deleted by switching off the dishwasher.

## Interrupting the Wash Programme (only in emergencies)

Interrupt a wash programme in progress **only when it is absolutely necessary to do so.** When the appliance is closed again, the air that has entered the appliance is heated and expands significantly. As result water may penetrate into the base of the appliance and trigger the leak prevention system.

Hot steam may escape from the appliance when opening the door. Open the door carefully.

☞ **1.** Open the door of the dishwasher.

**2.** Rectify the reason for opening the appliance.

**3.** Close the door. The selected programme will then continue.

## Setting or Changing the Delay Start Timer

Using the delay start timer it is possible to set a wash programme to start within the next 3, 6 or 12 hours.

☞ **1.** Press the ON/OFF button.

**2.** Press the button for the desired wash programme

**3. Setting the delay start:**
Keep pressing the ⏲ button until the indicator next to the number of hours of delay illuminates.
**Changing the delay start:**
As long as the wash programme has not started, you can still change the delay start set by pressing the ⏲ button.
**Cancelling the delay start timer:**
Providing the wash programme has not started you can cancel the delay start timer. Keep pressing the ⏲ button until none of the three hour displays is illuminated. The selected wash programme will begin immediately the dishwasher door is closed.

If a delay start is selected, the programme progress display does not illuminate.

**4.** Close the door.

## Load Sensing – Sensor Logic

If a wash programme is started even though there are only a few dishes in the upper and/or lower rack, an intelligent electronic system adjusts the amount of water and the duration of the wash programme to the number of dishes. By this means it is possible to wash only a few dishes quickly and economically. At half load (6 place settings), up to 2 litres of water and 0.2 kWh of electricity are saved.

## Switching Off the Dishwasher

Do not switch off the dishwasher until the display →| is illuminated. If the acoustic signal has been switched on there will be a continuous signal for 5 seconds at the end of the wash programme.

⚠ Hot steam may escape if the door is opened immediately after the end of the programme. Open the door carefully.

☞ **1.** Open the door.

**2.** Press the ON/OFF button.
The display in the ON/OFF button will go out.
If the dishwasher is not switched off, the acoustic signal is repeated after 10 minutes.

## Emptying the Dishwasher

ⓘ
- Hot dishes can be sensitive to knocks. The dishes should therefore be allowed to cool down before removing them from the appliance.
- Leave the dishes in the dishwasher for approx. 15 minutes after the end of the programme so that they dry better and can cool down.
- Empty the lower rack first, then the upper rack. This will avoid any water left on the upper rack dripping onto the dishes in the lower rack and causing water spots.

# Care and Cleaning

Do not under any circumstances use furniture care products or aggressive cleaners.

- If necessary, clean the controls only with a soft cloth and pure warm water.
- Occasionally check the internal containers, door seal, and water inlet for soiling, clean if necessary.

## Cleaning the Filter

The filters should be checked and cleaned regularly. Dirty filters will give poor wash results.




1. Open the door, remove the lower rack.
2. The dishwasher filter system comprises a coarse/fine filter, microfilter and a flat filter. Unlock the filter system using the handle on the microfilter, and remove.
3. Turn the handle about ¼ a turn anticlockwise and remove.
4. Take hold of the coarse/fine filter (1/2) by the handle with the hole and remove from the microfilter (3)
5. Clean all filters thoroughly under running water.
6. Remove the flat filter (4) from the base of the washing compartment and clean both faces thoroughly



**7.** Put the flat filter back in the base of the washing compartment

**8.** Place the coarse/fine filter in the microfilter and press together.

**9.** Put the filter combination in place and lock by turning the handle clockwise to the stop. During this process ensure that the flat filter does not protrude above the base of the washing compartment.




The dishwasher must not be used without filters under any circumstances.

# What to do, if ...

Try to rectify minor faults on the dishwasher with the aid of the instructions given here. If you call an engineer to resolve a of fault listed here, or to repair a fault caused by incorrect use or installation, a charge will be made even if the appliance is in guarantee.

## ... Warning tones indicating a fault in the dishwasher.

- If one or two repetitive warning tones can be heard after the start of a programme, they are indicative of a fault in the dishwasher that you can probably rectify yourself.
  After rectification of the fault, press the button for the wash programme that has been started and close the door of the dishwasher. The wash programme continues.
  If the same warning tone is heard again, please contact customer service.
- If more than two repetitive warning tones can be heard after programme start, please contact customer service. Customer service will need to know the number of tones and which indicators on the control and display field are flashing.

| Malfunction | Possible Cause | Solution |
|---|---|---|
| **1** continuously repeated **warning tone** can be heard, the programme display is flashing in the control and display field, and the control indicator is permanently illuminated: no water is running into the dishwasher. | Tap is blocked or furred with lime-scale. | Clean tap. |
| | The filter (where present) in the threaded hose fitting at the water inlet valve is blocked. | Clean the filter in the threaded hose fitting. |
| | The water inlet hose is not correctly laid. | Check hose installation. |
| **2 warning tones** that are continuously repeated can be heard, the programme display and the indicator on the control and display field are flashing. | The siphon is blocked. | Clean siphon. |
| | The water drain hose is not correctly laid. | Check hose installation. |
| **3 warning tones** that are continuously repeated can be heard and the and indicators on the control and display field are flashing. | The leak prevention system has been triggered. | Close the tap and contact your local AEG Sevice Force Centre. |

## ...there are problems with the operation of the dishwasher.

| Symptom | Possible Cause | Solution |
|---|---|---|
| The programme does not start. | The door of the dishwasher is not closed properly. | Shut the door. |
| | Mains plug is not plugged in. | Insert mains plug. |
| | House fuse in defective. | Replace fuse. |
| | A delay start is selected. | If the dishes are to be washed immediately, set the delay start to 0 hours |
| Rust spots are visible in the washing compartment. | The washing compartment is made of corrosion-resistant stainless steel. Rust spots in the washing compartment are from particles from outside the appliance (rust particles from the water pipe, from pans, cutlery, etc.). Remove such spots with a commercially available stainless steel cleaner. | Only wash cutlery and dishes that are suitable for dishwasher use. |
| | | Close the lid of the special salt container securely. |
| There is a whistling noise during washing. | The whistling is not a cause for concern. | Use a different brand of detergent. |
| Dishwasher interior lighting does not work. | Mains plug is not plugged in. | Insert mains plug. |
| | Light bulb for the interior lighting is defective. | Contact AEG Service Force. |

## ...the wash result is not satisfactory.

**The dishes are still dirty.**

– The wrong wash programme was selected.
– The dishes were arranged in such a manner that water has not reached all parts. The dish racks must not be overloaded.
– The filter in the base of the washing compartment is dirty or incorrectly positioned.
– Detergent was not used or too little was used.
– In the case of scale deposits on the dishes: the special salt container is empty or the water softener is incorrectly adjusted.

– The drain hose is incorrectly laid.

**The dishes are wet and dull.**
– Rinse aid was not used.
– The rinse aid container is empty.

**There are streaks, milky spots or a bluish coating on glasses and dishes.**
– Decrease rinse aid dosing.

**There are dried water drops on the glasses and dishes.**
– Increase rinse aid dosing.
– The detergent may be the cause. Contact the detergent manufacturer's consumer advisor.

# Technical Data

| | |
|---|---|
| Capacity: | 12 place settings including serving dishes |
| Permitted Water Pressure: | 1-10 bar (=10-100 N/cm$^2$ = 0.1-1.0 MPa) |
| Electrical Connection: | Information on the electrical connection is given on the rating plate on the inner edge of the dishwasher door on the right. |
| **Dishwasher: Free-Standing Appliances** | |
| Dimensions: | 850 x 600 x 600 (H x W x D in mm) |
| Max. Weight: | 54 Kg |
| **Dishwashers that Can Be Integrated, Built-In Dishwashers** | |
| Dimensions: | 820 – 880 x 596 x 570 (H x W x D in mm) |
| Max. Weight: | 50 Kg |
| **Dishwashers that Can Be Fully Integrated** | |
| Dimensions: | 820 – 880 x 596 x 546 - 550 (H x W x D in mm) |
| Max. Weight: | 50 Kg |

CE This appliance conforms with the following EU Directives:
– 73/23/EWG dated 19. 02. 1973 – Low Voltage Directive
– 89/336/EWG dated 03. 05. 1989
(including Directive Amendment 92/31/EWG) – EMC Directive

# Notes for Test Institutes

**Testing in accordance with EN 60704** must be carried out with the appliance fully loaded and using the test programme (see Programme Table).

**Tests in accordance with EN 50242** must be carried out when the salt dispenser and rinse aid container have been filled with salt and rinse aid respectively and using the test programme (see Programme Table).

| | **Full Load:**<br>12 place settings<br>incl. serving dishes | **Half Load:**<br>6 place settings incl. serving dishes,<br>leaving alternate positions free |
|---|---|---|
| Detergent Dosing: | 5g + 25g (Type B) | 20g (Type B) |
| Rinse Aid Setting: | 4 (Type III) | 4 (Type III) |

**Sample loading arrangements:**

Upper basket without cutlery tray



Upper basket with cutlery tray



Lower basket with cutlery basket



Cutlery basket



# INSTALLATION AND CONNECTION INSTRUCTIONS

## Installing the Dishwasher

- The dishwasher must be installed on a firm floor and adjusted to ensure that it is stable and level.
- To compensate for unevenness in the floor and to match the height of the appliance to that of surrounding units extend the threaded feet by unscrewing:
  – use a screwdriver.



- For built-in, integrated and fully integrated dishwashers, the rear feet should be adjusted from the front of the appliance using a screwdriver.
- The drain hose, inlet hose and mains cable must not be kinked or crushed when the dishwasher is in position.
- In addition, the dishwasher must be firmly screwed to the work surface or to the neighbouring units. This is essential to ensure the dishwasher does not tip.

# Fitting the Furniture Door Panel

(see installation template supplied)

The door of the appliance can be fitted with a furniture door panel of the following dimensions:

| | |
|---|---|
| Width: | 591 mm – 594 mm |
| Thickness: | 16 mm – 24 mm |
| Height: | max. 715 mm |
| Weight: | max. 10 kg |

# Connecting the Dishwasher

## Water Connection

The dishwasher is fitted with safety devices that prevent the wash water returning into the drinking water system and comply with the applicable plumbing regulations.

- The dishwasher must be connected to a cold water supply.
- The dishwasher **must not** be connected to open hot water appliances or instantaneous water heaters.

### Permitted water pressure

| | |
|---|---|
| Lowest permitted water pressure:<br>1 bar (=10 N/cm$^2$ =100 kPa) | Consult your installer if the water pressure is less than 1 bar. |
| Highest permitted water pressure:<br>10 bar (=100 N/cm$^2$ =1 MPa) | In the case of a water pressure greater than 10 bar, a pressure reduction valve must be used (available from your dealer). |

### Connect the inlet hose

The water inlet hose must not be kinked, crushed or entangled when it is being connected up.

☞ Connect the threaded hose fitting (ISO 228-1:2000) on the water inlet hose to a tap with an external thread (¾ inch). Tighten the threaded hose fitting **hand tight only**.

- In order that access to the tap in the kitchen is not limited by the use of the dishwasher, we recommend the installation of an additional tap, or fitting a two way adapter to the existing tap.
- If you need a longer water inlet hose than that supplied, VDE approved complete hose sets are to be used. These are available from your local Service Force Centre.
- Do not use, for connection, old hoses which have been used for another appliance.

The following section is only applicable to dishwashers that have a safety valve on the threaded hose fitting for the tap:

## Water inlet hose with safety valve

After connecting the double-walled water inlet hose, the safety valve is next to the tap. Therefore the water inlet hose is only under pressure while the water is running. If the water inlet hose starts to leak during this operation, the safety valve cuts off the running water and the draining pump in the dishwasher is switched on.

**Please take care when installing the water inlet hose:**

– The distance between the bottom edge of the safety value and the floor on which the dishwasher is standing must be at least 30 cm:




– The electrical cable for the safety valve is in the double-walled water inlet hose. Do not immerse the water inlet hose or the safety valve in water.
– If the water inlet hose or the safety valve is damaged, remove the mains plug immediately.
– A water inlet hose with safety valve must only be replaced by your local Service Force Centre.
– Place the water inlet hose in such a way that it is never higher than the bottom edge of the safety valve.



# Water drain

## Drain hose

The drain hose must not be kinked, crushed or entangled.

- Connecting the drain hose:
  – Maximum permitted height: 1 metre.
  – Minimum required height 30 cm above the lower edge of the machine.

## Extension hoses

- Extension hoses are available from AEG Service Force. The internal diameter of the extension hoses must be 19 mm to ensure that the function of the appliance is not impeded.
- Hoses may be laid a maximum of 3 metres horizontally; the maximum permitted height for the connection for the drain hose is then 85 cm.




## Sink outlet connection

- The outlet of the drain hose (ø 19 mm) fits all commonly available sink outlet spigot types. The outer diameter of the spigot connection must be at least 15 mm.
- The drain hose must be fixed to the sink outlet connection using the hose clamp supplied.

## If the dishwasher is fitted at a high position

If the dishwasher is installed at a high level, and the drainhose connection is less than 30 cm from the bottom of the appliance, adapter kit ET 111099520 must be fitted. This is available from Customer Service.

## Discharging into a standpipe

When discharging into a standpipe, the upright standpipe should have a minimum, length of 30 cm (12“) from the bottom of the elbow to the top of the pipe (see diagram). Make sure that it is designed in such a way that the end of the drain hose cannot be covered with water.



## Leak Prevention System

For protection from damage due to water leaks, the dishwasher is equipped with a leak prevention system, the AQUA CONTROL SYSTEM.

In the event of a fault, the safety valve immediately interrupts the supply of water to the appliance and the drain pump switches on. It is thus not possible for water to either leak or overflow. Any water left in the appliance is automatically pumped out.

The AQUA CONTROL SYSTEM also works when the appliance is switched off – the appliance must however **not** be disconnected from the mains.

When the appliance is switched on, a buzzing tone can also be heard.

## Electrical Connection

**Any electrical work required to install this appliance should be carried out by a qualified electrician or competent person.**

**WARNING – This appliance must be earthed.**
**The manufacturer declines any responsibility should these safety measures not be observed.**

Before switching on make sure the electricity supply voltage is the same as that indicated on the appliance rating plate.

To isolate the dishwasher from the mains, remove the mains plug.
**Important:** The plug must still be accessible after the appliance has been installed.

### Changing a fuse

The appliance is supplied with a 13amp plug fitted. In the event of having to change the fuse in the plug supplied, a 13amp ASTA approved (BS 1363A) fuse must be used.

Should the plug need to be replaced for any reason, proceed as described below.

The wires on the mains lead are coloured in accordance with the following code.

**Green and Yellow : Earth**
**Blue : Neutral**
**Brown : Live**




- The wire coloured green and yellow must be connected to the terminal marked with the letter “E“ or by the earth symbol ⏚ or coloured green and yellow.
- The wire coloured blue must be connected to the terminal “N“ or coloured black.
- The wire coloured brown must be connected to the terminal marked “L“ or coloured red.
- Upon completion there must be no cut, or stray strands of wire present and the cord clamp must be secure over the outer sheath.

**WARNING! A cut off plug inserted into a 13 amp socket is a serious safety (shock) hazard. Ensure that, if it is necessary to cut off the plug, it is disposed of safely and not retained.**

## Connections

The water inlet and drain hoses, as well as the mains cable must be connected beside the dishwasher as there is insufficient space behind the appliance.

The plumbing and electrical installation example given below can only be regarded as a recommendation.



# GUARANTEE CONDITIONS

**Guarantee Conditions**

AEG offer the following guarantee to the first purchaser of this appliance.

1. The guarantee is valid for 12 months commencing when the appliance is handed over to the first retail purchaser, which must be verified by purchase invoice or similar documentation.

   The guarantee does not cover commercial use.

2. The guarantee covers all parts or components which fail due to faulty workmanship or faulty materials. The guarantee does not cover appliances where defects or poor performance are due to misuse, accidental damage, neglect, faulty installation, unauthorised modification or attempted repair, commercial use or failure to observe requirements and recommendations set out in the instruction book.

   This guarantee does not cover such parts as light bulbs, removable glassware or plastic, dust bags or filters.

3. Should guarantee repairs be necessary the purchaser must inform the nearest customer service office (manufacturer´s service or authorised agent). AEG reserves the right to stipulate the place of the repair (i. e. the customer´s home, place of installation or AEG workshop).

4. The guarantee or free replacement includes both labour and materials.

5. Repairs carried out under guarantee do not extend the guarantee period for the appliance. Parts removed during guarantee repairs become the property of AEG.

6. The purchaser´s statutory rights are not affected by this guarantee.

**European Guarantee**

If you should move to another country within Europe then your guarantee moves with you to your new home subject to the following qualifications:

– The guarantee starts from the date you first purchased your product.
– The guarantee is for the same period and to the same extent for labour and parts as exist in the new country of use for this brand or range of products.
– This guarantee relates to you and connot be transferred to another user.
– Your new home is within the European Community (EC) or European Free Trade Area.
– The product is installed and used in accordance with our instructions and is only used domestically, i. e. a normal household.
– The product is installed taking into account regulations in your new country.

Before you move please contact your nearest Customer Care Centre, listed below, to give them details of your new home. They will then ensure that the local Service Organisation is aware of your move and able to look after you and your appliances.

| | | |
|---|---|---|
| France | Senlis | +33 (0) 44 62 29 29 |
| Germany | Nürnberg | +49 (0) 800 234 7378 |
| Italy | Pordenone | +39 (0) 800 117511 |
| Sweden | Stockholm | +46 (0) 8 672 5360 |
| UK | Slough | +44 (0) 1753 219899 |

# SERVICE AND SPARE PARTS

In the event of your appliance requiring service, or if you wish to purchase spare parts, please contact Service Force by telephoning:

**08705 929 929**

Your telephone call will be automatically routed to the Service Force Centre covering your post code area.
For the adress of your local Service Force Centre and further information about Service Force, please visit the website at www.serviceforce.co.uk

Before calling out an engineer, please ensure you have read the details under the heading „What to do if.....“

When you contact the Service Force Centre you will need to give the following details:

1. Your name, address and post code.
2. Your telephone number
3. Clear and concise details of the fault.
4. The model and serial number of the appliance (found on the rating plate).




5. The purchase date

Please note that a valid purchase receipt or guarantee documentation is required for in-guarantee service calls.

**Customer Care**

For general enquiries concerning your AEG appliance or for further information on AEG products please contact our Customer Care Department by letter or telephone at the address below or visit our website at www.aeg.co.uk.

Customer Care Department
AEG Domestic Appliances
55-77 High Street
Slough
Berkshire, SL1 1DZ

Tel. 08705 350350 (*)

(*) Calls may be recorded for training purposes

*The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. 14 billion USD in more than 150 countries around the world.*

***From the Electrolux Group.*** *The world's No.1 choice.*

AEG Hausgeräte GmbH
Postfach 1036
D-90327 Nürnberg

http://www.aeg.hausgeraete.de

© Copyright by AEG

822 946 343 - 01 - 0602

Subject to change without notice